

IF YOU INHALE TOO MUCH NICOTINE OR USE THE PRODUCT TOO MUCH YOU MAY EXPERIENCE ONE OR MORE OF THE FOLLOWING EFFECTS

- Feeling faint
- Headache
- Nasal congestion
- Chest palpitations

- Nausea (feeling sick)
- Coughing
- Dizziness
- Hiccups

- Irritation in the mouth or throat
- Stomach discomfort
- Vomiting (being sick)
- Abnormal heart rate

• Those experiencing general ill health; such as heart disease, If you experience any of the above side effects including any possible side effects not listed in this user manual, discontinue using the product. If the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.

DO NOT USE NICOTINE-CONTAINING E-LIQUIDS:

- If you are allergic to nicotine or any of the other ingredients contained in the e-liquid (see manufacturer's label for full details).

ADDICTIVENESS

Nicotine is highly addictive; and is therefore intended for adult smokers only.

HOW TO STORE AN ELECTRONIC CIGARETTE

Always power off the electronic cigarette when it is not being used, or when it is going to be stored. Store the electronic cigarette in room temperature (5°C to 30°C) in a clean dry place. Keep the product out of sight and reach of children and animals.

HOW TO DISPOSE OF AN ELECTRONIC CIGARETTE

The electronic cigarette contains a rechargeable battery which should be recycled in a designated waste disposal site. Please dispose of your electronic cigarette responsibly with consideration to the environment.

BATTERY CARE GUIDE

READ BEFORE USE!

INTERNAL BATTERY

- Do not leave device unattended while charging.
- Charge promptly based on battery level. Keep a charge of more than 10% to maximize battery lifespan.
- Use a standard output charger and charging cable with the correct charging current and voltage range.
- Do not use with a car charger.
- Do not leave device charging for extended periods of time. Stop charging when the battery is full.
- Carefully insert the USB-C plug correctly. Do not use force or the port may be damaged.
- Check with your airline before flying with your vaporizer.

European Representative:

Greentech Import-Export B.V.

Address: Arendstraat 7

ZIP Code: 6135 KT

City: Sittard

Country: The Netherlands

Email: contact@gtimport.eu

Manufacturer:

Shenzhen Vapewell Technology Co., Ltd.

Address:

3rd Floor, Building 10, Xinxintian Industrial Park, Xinsha Road, Shaer Community, Shajing, Baoan District, 518104, Shenzhen, China.

Telephone: +86 755 2768 5365

Email: info@innokin.com

Website: www.innokin.com

Production License: 5144030172

ISO 9001 and ISO 14001 Certified.




PLEXUS

PRO

Power in Every Draw.

POWERED BY INNOKIN®

COMPONENTS



Adjusting the Airflow

Adjust the airflow control for your desired draw.

Fill the Cartridge

Slide open the cap in the direction of the ▲ arrow mark to fill the cartridge.

Important

- Wait for at least five minutes after filling to allow the new cartridge to saturate with E-liquid.
- Avoid letting the cartridge run completely dry. Refill it regularly to

Power On/Off the Device

Press the power button five times quickly to turn the device on or off.

Home Screen

Battery Level

Wattage

Coil Resistance

Puff Count



Manual Lock/Unlock

- Lock: Press the power button 4 times quickly → Screen shows "Locked" → Fire Trigger & wattage adjustment disabled.
- Unlock: Press the power button 4 times quickly.

Auto Lock

- Auto lock is activated upon 10 mins. of inactivity.
- Effect: Fire Trigger & wattage adjustment disabled; other functions available.
- Unlock: Press the button 4 times quickly or vaping via auto-draw.

Wattage Adjustment

1. Press the power button three times consecutively until the numbers start flashing to enter wattage adjustment mode.
2. Press the power button to adjust the wattage in 1.0W increments with a full range of 6-25W (coil dependent).
3. Wait for five seconds to exit the wattage adjustment mode.

Coil	Adjustable wattage range
0.6Ω	6 - 25W
0.8Ω	6 - 16W
1.2Ω	6 - 13W
1.35 - 3.5Ω	6 - 13W

Charging

- Charge the device promptly based on the battery level.
- Use USB-C charging cable and a standard output charger with the correct charging current and voltage range.
- Charging pauses during vaping and resumes after vaping.
- During charging, the battery percentage is displayed with an animated indicator. The screen turns off once fully charged.

Caution

- Turn the device off when not in use to avoid depleting the battery and minimize excess battery wear.
- Avoid dropping, throwing, or mishandling the device to prevent damage.
- Protect the device from direct sunlight, dust, moisture, or mechanical shock.
- Keep the device away from any water, liquid, or flammable gas.
- Keep the contents of this package out of reach of children, non-smokers and animals.
- Do not leave the device charging while unattended.
- Do not use it if pregnant or breast-feeding.
- Warning: Do not use this product if you suffer from heart disease, severe hypertension, diabetes, stomach ulcers or have a history of seizures.

EEE Recycling

This product is meant to be disposed of in an approved e-waste receptacle or recycling bin. Do not throw it away in standard waste receptacles.

Specifications

Dimensions: Ø20 ×13.24 mm

Pod Capacity: 2.0 mL

Coil: 0.6Ω(20-25W)/0.8Ω(13-16W)/1.2Ω(10-13W)

Output Power: Max.25W

Built-in Battery Capacity: 1350mAh

Charging Current: DC 5.0V/2.0A

Draw-activated Vape/Button-activated Vape

Protections

- Low Battery Protection – Displays LOW VOLT and stops output when battery voltage is low.
- Coil Error Protection – Displays CHECK COIL and stops output if atomizer resistance is too low.
- 10-Second Cut-off – Displays TIME OUT and stops output after a single puff exceeds 10 seconds.
- Overheat Protection – Displays HIGH TEMP and stops output if PCB temperature is too high.
- Short Circuit Protection – Displays COIL SHORT and stops output if a short circuit is detected during use.
- Low Resistance Protection – Displays LOW RES and stops output if atomizer resistance is too low before firing.

SAFETY GUIDELINES AND WARNING:

PLEASE READ THIS SECTION CAREFULLY TO ENSURE YOU RECEIVE MAXIMUM BENEFITS FROM THE PRODUCT AND ENJOY VAPING WITH IT IN THE MOST SAFE AND EFFECTIVE WAYS POSSIBLE.

1. THIS PRODUCT IS INTENDED FOR USE BY ADULTS OF LEGAL SMOKING AGE (18+ OR HIGHER). THIS PRODUCT IS NOT RECOMMENDED FOR NON-SMOKERS, YOUNG PEOPLE UNDER THE AGE OF 18 YEARS, PREGNANT OR BREAST FEEDING WOMEN AND THOSE EXPERIENCING GENERAL ILL HEALTH.
2. THIS PRODUCT MAY BE USED WITH E-LIQUIDS THAT CONTAIN NICOTINE. IF YOU ARE USING E-LIQUID CONTAINING NICOTINE PLEASE REFER TO THE INFORMATION PROVIDED IN SECTION "IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS" OR CHECK WITH YOUR E-LIQUID PROVIDER FOR MORE INFORMATION.
3. THIS PRODUCT IS ONLY DESIGNED TO BE USED WITH HIGH QUALITY E-LIQUID. IT IS NOT INTENDED FOR USE WITH LOOSE TOBACCO LEAF OR HERBAL SUBSTANCES. INNOKIN IS NOT RESPONSIBLE FOR ANY ATOMIZER OR BATTERY DAMAGE DUE TO THE USE OF LOW QUALITY E-LIQUID, DRY HERB, OR OTHER MATERIALS FOR WHICH THIS PRODUCT WAS NOT DESIGNED.
4. THIS PRODUCT IS NOT INTENDED TO TREAT, MITIGATE, PREVENT OR CURE ANY DISEASE OR CONDITION. IT IS NOT INTENDED FOR USE AS A SMOKING CESSATION DEVICE.
5. ALWAYS KEEP THIS PRODUCT OUT OF REACH OF CHILDREN AND PETS.

6. DO NOT MISUSE, MISHANDLE OR STORE THIS PRODUCT IMPROPERLY. IN ORDER TO PROLONG THE OPERATION OF THIS PRODUCT, PLEASE DO NOT USE, PLACE OR STORE IT IN EXCESSIVELY HOT OR COLD ENVIRONMENTS.
7. DO NOT ATTEMPT TO REPAIR THE PRODUCT BY YOURSELF AS DAMAGE OR PERSONAL INJURY MAY OCCUR.
8. THIS PRODUCT IS NOT WATERPROOF. KEEP IT DRY AT ALL TIMES.
9. DO NOT ALLOW ANY LIQUIDS OR E-JUICE TO ENTER THE DEVICE THROUGH THE TOP THREADING OR THE USB PORTS. IF ANY LIQUIDS ENTER THE DEVICE, OR COME INTO CONTACT WITH THE PCB, PLEASE DISCONTINUE USING OR CHARGING THE DEVICE AND CONTACT YOUR LOCAL AUTHORIZED INNOKIN VENDOR IMMEDIATELY.
10. INNOKIN IS NOT RESPONSIBLE FOR BATTERY AND CHARGER EXPLOSIONS, OR MALFUNCTIONS, DUE TO THE USE OF A LOW-QUALITY CHARGER. ONLY USE THE ORIGINAL MICRO USB CABLE TO CHARGE THE DEVICE. WE RECOMMEND THAT YOU USE A HIGH QUALITY USB WALL CHARGER (CE/UL CERTIFIED).
11. THIS PRODUCT IS NOT DESIGNED FOR USE WITH A CAR CHARGER. THIS PRODUCT DOES NOT COME INCLUDED WITH A CAR CHARGER.
12. OBEY LOCAL LAWS OR REGULATIONS REGARDING ELECTRONIC CIGARETTES WHEN VAPING. IF YOU ARE IN AN AREA WHERE THERE ARE ANY BANS OR POTENTIAL DANGERS, PLEASE DO NOT USE THIS PRODUCT.

IMPORTANT INFORMATION ABOUT USING NICOTINE-CONTAINING E-LIQUIDS

BEFORE USING NICOTINE-CONTAINING E-LIQUIDS THE USER SHOULD READ THE FOLLOWING INFORMATION CAREFULLY.

WARNINGS AND PRECAUTIONS

DO NOT USE NICOTINE-CONTAINING E-LIQUIDS:

- If you are allergic to nicotine or any of the other ingredients contained in the e-liquid (see manufacturer's label for full details).

NICOTINE-CONTAINING E-LIQUIDS ARE NOT RECOMMENDED FOR:

- Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma.
- Those who have an overactive thyroid gland or have a pheochromocytoma (a tumour of the adrenal gland that can affect high blood pressure)
- Those who have diabetes, as nicotine may affect your blood sugar levels
- Those taking the following medication: Theophylline (to treat breathing problems); Ropinirole (to treat restless legs); Clozapone (to treat schizophrenia)