


# INNOKIN ENDURA T20 S



FLIP FOR MORE INFO

## REFILLING THE TANK



- 1) Unscrew Top Cap.
- 2) Fill Against Side of Tank.
- 3) Wait 5 Minutes before Vaping.

### CAUTION:

Do not vape if low on eliquid.  
Stop if there is a burnt taste.  
Replace the coil if there is a  
reduction in flavor or vapor.

## REPLACE THE COIL




### CAUTION:

Make sure there is no eliquid in the  
tank before removing the coil.

Please refer to User Manual for full operating instructions on  
[WWW.INNOKIN.COM](http://WWW.INNOKIN.COM)

# INNOKIN ENDURA T20 S



FLIP FOR MORE INFO