

3 3X CLICKS TO TURN ON



4 SELECT COIL



COIL TYPE 0.21Ω  
SAME Ni Ti SS W

WATTAGE COIL  
TEMP. COIL

W SS  
Ni Ti SS

WATTAGE

RESISTANCE BATT. LIFE  
0.65Ω 15.0W  
VOLTAGE PUFF TIME  
0.00V 0.00S

TEMP. CONTROL

RESISTANCE, WIRE TYPE  
0.10Ni 180°C  
WATTAGE TEMP. (C OR F)  
70.0W 0.00S

5 ADJUST SETTINGS AS DESIRED



6 ENJOY THE VAPOR

For full content, please refer to user manual on the product page at INNOKIN.COM

QUICK REFERENCE GUIDE

BATTERY LIFE INDICATOR



FULL HALF LOW\*

SETTINGS AND MODES

HOLD + ADJUST V/W/TEMP. UP

HOLD - ADJUST V/W/TEMP. DOWN

PRESS + - FOR PRECISE READING: RESISTANCE/VOLTS/PUFF #

HOLD + - FLIP DISPLAY ORIENTATION

HOLD [Power] + MODE SELECT (Ni/Ti/SS/W)

HOLD [Power] - ADJUST RAMP UP WATTAGE IN TC MODE

SUPPORT

- facebook.com/Innokin.Technology
- instagram.com/innokintechnology
- twitter.com/innokintech
- reddit.com/r/innokin
- support@innokin.com

INNOKIN

iSub-B  
+  
KROMA-A  
QUICK START GUIDE



FLIP FOR MORE INFO

\*The product images shown are for illustration purposes only and may not be an exact representation of the product.

QUICK START GUIDE

- Attach & Fill the iSub-B Tank.
  - Power on the Kroma-A, [3x Power]
  - Press [+] 4x to Select [W] Wattage Mode. Press [Power] to Select.
  - Hold the [+] Button until the Wattage Flashes.
  - Use [+] - [-] Button to set Wattage.
  - Start low and increase wattage to preferred heat and flavor.
  - Adjust iSub-B Airflow to your preferred draw.
  - Press the Power Button to Vape & Enjoy!
  - **Do not exceed recommended Wattage or the coil may be damaged.**
  - \*Power Off the Kroma-A when not in use.
- Read the Battery Safety Guide for important information.  
If you have any questions please write to support@innokin.com.

INSTRUCTION

- 1 ATTACH TANK
- 2 UNSCREW CAP AND TOP FILL PLEASE WAIT 5 MINUTES FOR COIL TO SATURATE.

